## danalogic Actio BTE LED Light control settings

	Action of	Turn on	Turn off	In charger		Law battam
	software	Turn on	Turn on	Charging	Fully charged	Low battery
LED Light control settings	Disabled			000		
	Flash Once			•		
	Continuous Flash		000	•••		

	Action of software	Change volume	Volume limit	Programme status	DAI	Flight mode
LED Light control settings	Disabled	No light	No light	No light	No light	No light
	Flash Once	1 x when pressed	1 x when reached	Programme 1 Programme 2 Programme 3 Programme 4 1 x when pressed	1 x when activated	1 x when activated (1 long blink, then four double blinks)
	Continuous Flash	1 x when pressed	1 x when reached	Programme 1 Programme 2 Programme 3 Programme 4 1 x when pressed	1 x when activated	1 x when activated (1 long blink, then four double blinks)

## Notes:

• Low battery warning takes priority over all other indicators.



For further support, scan the QR code or visit our patient support portal at: danalogic.co.uk/patient-portal

